

DRAPER BELT REPAIR KIT

P/No. DRAPBEL-KIT-1



adelaide
belt & hose
Australia



Patching Material
430 x 430 x 1mm



500ml



236ml

DIRECTIONS

Materials may need cleaning or roughing up before cementing. Apply an even coat to BOTH surfaces to be joined and let dry only 2-5 minutes. Press together. Bond strength increases with age as cement sets. Keep container tightly closed when not in use.